

HUME DOORS & TIMBER

100% Australian Owned



2022

SKIRTING & ARCHITRAVE PRODUCT CATALOGUE



Sillatrim® HMR MDF Moulding Profiles

Silktrim mouldings are manufactured to allow for a straightforward and rapid installation, while providing the perfect primer for an excellent paint finish. Elegant styles and stable engineered construction, is why Silktrim is the sought after option for final fit out stages in new homes and commercial developments.

SILKTRIM® PRODUCT INFORMATION, INSTALLATION & USE

Information for Installers

3 General Installation

Health & Safety

3 Care & Maintenance

3 Points to Consider

Environmental Commitment

SILKTRIM® PROFILE DRAWINGS

Dressed All Round | 12mm DAR E2E

Dressed All Round | 18mm DAR E2E 4

Dressed All Round | 30mm DAR E2E 6

Dressed All Round | DAR S4S 6

7 12mm Pencil Round

7 18mm Pencil Round

8 18mm Half Splayed

9 12mm Half Splayed

9 NSW Half Splayed

9 Melbourne Half Splayed

10 12mm Single Bevel

10 15mm Single Bevel

11 18mm Single Bevel

12 Bullnose

13 SA Bullnose

13 WA Bullnose

13 WA Double Bullnose

14 **NSW Colonial**

15 **Oueensland Colonial**

15 Victorian Colonial WA Colonial

16 Australian Colonial

17 Lambs Tongue

NSW Classic 18

18 Berkley

19 New Replica

19 WA Federation

20 Olympic

20 NSW Step

21 SA Single Step

21 Provincial Step

22 Single Housing Trust

22 Small End Section Mouldings

23 Single Nosing

23 Capping

24 Shelf Support

24 VJ Lining Board

25 18mm Beveled Loose Stop Jamb Set

25 18mm Loose Stop Jamb Set

26 30mm Loose Stop Jamb Set

WARRANTY

27

Hume Doors & Timber Warranty

BRANCH LOCATIONS

28 Hume Doors National Locations



- Highly moisture resistant, medium density fibreboard (HMR MDF).
- Safe to you and the environment (low formaldehyde levels) (E0).
- Innovative priming system using the very best formulations to provide the greatest pre finishing coat on the market.

Information For Installers

General Installation

The Silktrim product range can be installed by an advanced DIYer or above.

General carpentry and woodworking tools are all you will need to install Silktrim Moulding Range.

Although the Silktrim range is supplied pre-sanded and pre-primed, cut ends will require sealing before installation.

Once installed the nails need to be punched 2mm below the surface of the board, filled with an exterior wood filler, sanded and spot primed before being coated with a minimum of two coats of high-grade acrylic paint. For alternative coatings, contact your paint supplier.

Health & Safety

When installing the Silktrim product range take all necessary steps to ensure your safety and the safety of others:

- When you are cutting or drilling ensure there is adequate ventilation or mechanical dust extraction.
- Ensure the product is well supported when you are cutting and nailing.
- Use safety glasses, ear protection, and wear appropriate clothing and footwear
- Use all tools in accordance with the relevant instruction manuals.
- Clear the work area of any obstructions before you start.

Care & Maintenance

As with any timber product, to get the best performance, regular cleaning and maintenance is required.

Hume Doors & Timber recommends that at least once a year the product is washed down with a mild detergent and a fine brush to remove dirt.

We do not recommend using a water pressure cleaner, as this can damage the surface coating.

Paint finishes in general will require re-coating, approximately every 3–5 years, or more frequently if the paint coating has been damaged. This will depend on site-specific exposure.

Points to Consider:



General Information:

- Site-specific conditions including not to be used in a wet area application. This will void all Warranty.
- Other materials likely to impact on performance of the installed moulding.
- And anything else relevant to the project.



Installation

- Prepare boards by priming all cut ends with two coats of premium acrylic primer undercoat to end-seal.
- Fill all nail holes with filler, then sand and prime.
- Finish with a minimum of two coats of a high grade acrylic primer.



On Site Storage

Store flat, covered and 150mm off the ground to maintain the desired moisture content.



Care & Maintenance

- Wash down at least annually, using a mild detergent and a soft brush.
- Recoat every 3–5 years with two coats of acrylic topcoat or as per paint manufacturer's recommendations.



Hume Safety


- Ventilated working areas.
- PPE (personal protective equipment).
- Correct tools for the job.

Environmental Commitment:


Hume Doors & Timber is committed to operating its entire business in an environmentally sustainable manner at all times including but not limited to:

- Hume solar power scheme Reducing our carbon footprint.
- Reusing and recycling by-products, packaging and waste material.
- Reducing the levels of consumables used.
- Capturing, storing and using rainwater for our water needs.
- Maximise transport needs, thus reducing our energy requirements.

Dressed All Round | 12mm DAR E2E




Dressed All Round | 18mm DAR E2E







Dressed All Round | 18mm DAR E2E (continued)




Dressed All Round | 30mm DAR E2E




Dressed All Round | DAR S4S



12mm Pencil Round





18mm Pencil Round



7

18mm Half Splayed













12mm Half Splayed






NSW Half Splayed



Melbourne Half Splayed




12mm Single Bevel



15mm Single Bevel



18mm Single Bevel











Bullnose



SA Bullnose




WA Bullnose






WA Double Bullnose





NSW Colonial











Queensland Colonial






Victorian Colonial













WA Colonial








Australian Colonial







Lambs Tongue











NSW Classic









Berkley





18


New Replica




WA Federation




Olympic




NSW Step




SA Single Step




Provincial Step




Single Housing Trust




Small End Section Mouldings







Single Nosing





Capping







Shelf Support




VJ Lining Board




18mm Beveled Loose Stop Jamb Set



18mm Loose Stop Jamb Set



30mm Loose Stop Jamb Set





This Warranty applies to Hume Doors & Timber Silktrim® products supplied for use as an internal finishing timbers/moulding product.

Warranty Period:

- 5 years from proven date of purchase.
- All inquiries relating to this Warranty must be directed to the supplier or installer in the first instance.

Hume Doors & Timber Warrants That:

At the time of delivery to the merchant or site (where applicable), Silktrim will be free from factory defects and conforms to the current Hume Doors & Timber warranted condition.

In The Event of Proven Product Failure of Silktrim® products to Meet the Warranted Condition, Subject to the Terms of This Warranty, the Following Applies:

- Hume Doors & Timber will at its discretion, supply replacement Silktrim product without charge, or refund the value of the product. The installer will be responsible for the cost of removing and installing any replacement materials.
- Other losses or damage caused by product failure are not covered.
- Hume Doors & Timber's obligations under this Warranty are limited to the replacement of defective Silktrim product or the value of the Silktrim Product. The value of the materials will be reduced pro-rata based on the remaining life of the product.
- Hume Doors & Timber reserves the right to supply other compatible materials for repair should the warranted materials no longer be supplied by Hume Doors & Timber.

This Warranty is Subject To:

- Proof of date of purchase of the product.
- Evidence of failure.
- Receipt of a written claim from the claimant either within 30 days of when the defect would have become reasonably apparent, or, if the defect was reasonably apparent prior to installation, then the claim must be made prior to installation. The claim must include full details of the alleged defect, including a copy of the proof of purchase. Any claim is subject to inspection by Hume Doors & Timber before any remedial action is undertaken.
- Evidence satisfactory to Hume Doors & Timber that all storage, handling and maintenance requirements (as advised by Hume Doors & Timber) has been carried out.
- The Warranty does not cover failure or problems caused by defective use, failure relating to improper design of the project structure, structural failure, settlement, movement of materials to which the product is attached or dependent on, acts of God including but not limited to earthquakes, cyclones, floods or other severe weather conditions, inadequate maintenance, growth of mould, mildew, fungi, bacteria or any organism on any product, or has acts or omissions of a third party over whom Hume Doors & Timber has no control.
- The Warranty does not cover product failure arising from the failure to follow Hume Doors & Timber design, installation, storage, handling or maintenance advice.
- Normal wear and tear is excluded from this Warranty.

CONTACT DETAILS



QUEENSLAND



HUME DOORS & TIMBER (QLD) PTY LTD

ABN 25 009 994 996

86 – 92 Mudgee Street, Kingston QLD 4114 PO Box 2243, Logan City D.C. QLD 4114

P | 07 3489 6200

F | 07 3489 6299

E | sales@humedoorsqld.com.au

Sunshine Coast Branch:

14 Junction Drive, Coolum Beach Qld 4573

P | 07 5446 2640

F | 07 5446 3530

E | hdtcoolum@humedoorsqld.com.au

Cairns Branch:

4 – 6 Ponzo Street, Woree, QLD 4868

P | 07 4041 2099

E | hdtcairns@humedoorsqld.com.au

Northern Territory Branch:

3 Adams Road (Cnr Beresford),

Yarrawonga NT 0830

P | 08 8932 3733

F | 08 8932 3799

E | hdtnt@humedoorsqld.com.au

NEW SOUTH WALES



HUME DOORS & TIMBER - (AUST) PTY LTD

ABN 39 001 472 493

Sydney Office & Showroom:

120 Hume Highway, Lansvale NSW 2166 PO Box 333, Cabramatta NSW 2166 P | 02 9794 1111 | 02 9794 1199

E | info@humedoors.com.au

Newcastle Branch:

7 Waterloo Avenue, Thornton NSW 2322

P | 02 4966 8880

F | 02 4966 8881

E | nclsales@humedoors.com.au

Port Macquarie Branch:

No. 2 Belah Road, Port Macquarie NSW 2444

P | 02 6581 0011

F | 02 6581 0091

E | pmsales@humedoors.com.au

HUME DOORS & TIMBER (VIC) PTY LTD

ABN 87 006 329 906

33 Remington Drive, South Dandenong VIC 3175 PO Box 4236, South Dandenong VIC 3164

P l 03 9799 6888

F 03 9799 9688

E | hdtvic@humedoors.com.au

Tasmanian Branch:

5 Trotters Lane, Prospect Tasmania 7250 PO Box 393 Prospect Tasmania 7250

P | 03 6774 9100

E | tassales@humedoors.com.au

SOUTH AUSTRALIA

HUME DOORS & TIMBER (SA) PTY LTD


ABN 34 007 512 209

89 Heaslip Road, Burton SA 5110

E | hdtsa@humedoors.com.au

PO Box 2037, Salisbury Downs SA 5108 P | 08 8280 2000

F | 8 8280 8099





HUME DOORS & TIMBER (WA) PTY LTD

ABN 62 009 421 569

75 Briggs Street, Carlisle WA 6101 PO Box 118, Welshpool WA 6986

P | 08 9470 1800

F | 08 9472 3802

E | hdtwa@humedoors.com.au

Disclaimer: Hume Doors & Timber reserves the right to alter or amend without prior notice, any data, dimensions and design details specified herein. Photographs or illustrations may not depict the exact design or specification and may vary to the actual product. Products are supplied unfinished unless otherwise specified.